



## 25G InGaAs Avalanche Photodiode TIA ROSA-LC Package

### Description

A 25 Gb/s InGaAs Avalanche photodiode packaged with a transimpedance amplifier (TIA). This device is packaged in a TO-Can with LC receptacle. It comes configured with a Flex PCB. The device features an optional LC-Flange receptacle for easy LC fiber optic cable insertion. Offering flat response and a broad temperature operating range.

### Features

- TO-Can Package
- LC- Receptacle
- 25 Gbps
- Wide Temperature operating range
- TIA Built-in
- -24 dBm Typical sensitivity
- 1K Ohm Transimpedance Gain



### Applications

- Telecommunications
- RF over Fiber (RToF)



IMPORTANT NOTICE: more information on warranty, changes, rights, notices, and other information are presented at the back of this data sheet. If the back sheet is not present, refer to [www.nuphotonics.com](http://www.nuphotonics.com) for the company issued data sheet.

**Electro-Optical Characteristics (T = 25°C)**

Parameter	Symbol	Min.	Typ.	Max.	Unit	Test Conditions
Supply Voltage	$V_{cc}$	-	3.3	3.6	V	
Supply Current	$I_{cc}$	-	26	35	mA	$V_{cc} = 3.3\text{ V}$
Response Spectrum	$\lambda$	1260	-	1600	nm	$V_{cc} = 3.3\text{ V}$
Bandwidth	BW	-	21	-	GHz	-3 dB bandwidth
Overload	OL	2.2	-	-	dBm	$V_{cc} = 3.3\text{ V}$
Sensitivity	Sen	-	-	-22	dBm	25.78 Gbps, 1310 nm, ER = 4 dB, BER = $10^{-5}$
Optical Return Loss	ORL	-	-	-27	dB	CW = 1310 nm
RSSI Offset Current	$I_{RSS}$	-	-	100	nA	$V_{cc} = 3.3\text{ V}$
Responsivity	R	0.7	0.8		A/W	1310 nm, 50 % VBR, Pin -20 dBm
Dark Current	$I_d$	-	100	-	nA	VBr
Output Impedance	$Z_o$	-	100	-		Differential
Maximum Output Voltage	$V_o$	-	300	-	mV <sub>p-p</sub>	Differential
Low Frequency Cutoff	$F_{low}$	25	100	-	KHz	
APD Supply Voltage	$V_{apd}$	20	-	27	V	

**Absolute Maximum Rating (T = 25°C)**



Parameter	Symbol	Condition	Min.	Max.	Unit
TIA Voltage	$V_{tia}$	-	-	3.6	V
Input Optical Power	$P_{in}$	-	-	5	dBm
APD Supply Voltage	$V_{apd}$	-	-	33	V
Storage Temperature	$T_{stg}$	-	-40	90	°C
Storage Humidity	$H_{stg}$	-	-	85	% r.H.
Operating Temperature	$T_{op}$	-	-40	85	°C
Soldering Temperature	$T_{st}$	10 sec	-	260	°C
ESD Susceptibility		HBM	100	-	V


Operating at maximum operating specs for prolong periods of time will damage the device.




**Typical Performance Curves** (Top 23°C, 801 PTs, 16 AVGs, 1.5% smoothing)

RF performance dependent on PCB design and optimization. Data shown for Rogers ® RO3003 with Ground-backed Co-planar waveguide (GB-CPW). The GB-CPW was de-embedded. Single ended measurement, port two is terminated with 50 Ohm load.





Flexible PCB Pinout



Pad	Function
1	Vcc
2,5	GND
3	Dout (-)
4	Dout (+)
6	Vapd



**Product Line –25G PIN  
photodiode W/ TIA**

**Device body style – TO-CAN**

A – Without Flange  
B – With Flange

Example – AP25T-TO-LC-B

## 25G Avalanche Photodiode LC Receptacle with Flange

## Mechanical Drawing



NuPhotonics

# IMPORTANT NOTICES AND DISCLAIMERS

Warranty: NUPHOTONICS PROVIDES ALL OF THE INFORMATION ON TECHNICAL AND RELIABILITY DATA. THIS INCLUDES INFORMATION PRESENTED IN DATA SHEETS, DESIGN FILES, APPLICATIONS, AND OTHER RESOURCES “AS IS” AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD-PARTY INTELLECTUAL PROPERTY RIGHTS.

The information and resources are presented and intended for developers that are skilled and adequately qualified to work with this technology. You, the customer, are solely responsible for and accept full responsibility for selecting the appropriate NuPhotonics devices for your application. You accept the sole responsibility of designing, validating, and testing your application. You bear all responsibility for your application meeting standards, safety, security, and other regulatory requirements.

NuPhotonics retains the right to change these resources without notice. All rights are reserved for NuPhotonics. NuPhotonics grants you permission to use the information in these resources to design with NuPhotonics devices. Reproduction and display of these resources is prohibited. No Third-party licenses are offered. You will fully indemnify NuPhotonics against any claims, damages, costs, losses, and liabilities that arise from you using these resources.

NuPhotonics does not accept and objects to any terms you have proposed.

For terms and conditions for all NuPhotonics products please refer to [www.nuphotonics.com](http://www.nuphotonics.com) Legal section.

Definitions: Product State

Alpha Build: Devices in Alpha build are in internal engineering build and testing stages. Major changes may happen for production build.

Beta Build: Devices in Beta build are for external customer and engineering sample testing stages. Minor changes may happen for production build.

Production Build: Customer ready devices. Small appearance changes may occur between devices.

Obsolete: Currently not supported.

Copyright © 2026, NuPhotonics LLC

## Revision History

1.5 – January 2026 – Included LC Flange drawing. Updated device Body drawing.

1.4 – March 2024 – Updated Mechanical drawing, Included low frequency data.

1.3 - March 2024 - Corrected pinout for APD pinout.

1.0 – December 2023 – Initial Release.